Belkin Corporation Limited 3-Year Product Warranty

Belkin Corporation warrants this product against defects in materials and workmanship for three years. If a defect is discovered, Belkin will, at its option, repair or replace the product at no charge provided it is returned during the warranty period, with transportation charges prepaid, to the authorized Belkin dealer from whom you purchased the product. Proof of purchase may be required. This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication; if the product has been modified without the written permission of Belkin; or if any Belkin serial number has been removed or defaced.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESSED OR IMPLIED. BELKIN SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

No Belkin dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

BELKIN IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPROGRAMMING OR REPRODUCING, ANY PROGRAM OR DATA STORED IN OR USED WITH BELKIN PRODUCTS.

Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusion of implied warranties, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

belkin.com

Belkin Corporation
501 West Walnut Street
Compton • CA • 90220 • USA
Tel: 310.898.1100
Fax: 310.898.1111

Belkin Components, Ltd.
Express Business Park • Shipton Way
Rushden • NN10 6GL • United Kingdom
Tel: +44 (0) 1933 35 2000
Fax: +44 (0) 1933 31 2000

Belkin Components B.V.
Starparc Building • Boeing Avenue 333
1119 PH Schiphol-Rijk • The Netherlands
Tel: +31 (0) 20 654 7300
Fax: +31 (0) 20 654 7349

Belkin, Ltd.
7 Bowen Crescent • West Gosford
NSW 2250 • Australia
Tel: +61 (0) 2 4372 8600
Fax: +61 (0) 2 4372 8603

Tech Support
US: 310.898.1100 ext. 2263
800.223.5546 ext. 2263
Europe: 00 800 223 55 460
Australia: 1800 666 040

P74297

Media Reader for iPod

Store thousands of digital photos on your iPod™



User Guide

F8E461

Setup Instructions

1. Turn the iPod on.

2. Insert a media card into the Media Reader and connect the device to the iPod.

3. Select "Extras > Photos > Import Photos > Import".

4. Photos are listed on the iPod by roll number.

NOTE: The Photos menu item doesn't appear unless you connect the Media Reader.

To view information about photos stored on iPod:

1. Select "Extras > Photos" and choose the roll number.

2. The type of media, number of photos, and size of the roll are displayed.

NOTE: You CANNOT view the actual photos on the iPod.

To erase photos from a photo card:

1. Insert a media card into the Media Reader and connect the device to the iPod.

2. Select "Extras > Photos > Import Photos > Erase".

NOTE: ALL photos are deleted from the Media Reader when this function is performed.

To transfer photos to your computer:

- Connect iPod to your computer and open the application you use to transfer photos from your digital camera or media device. See the documentation that came with the application for more information. If you are using a Macintosh® computer, you can use iPhoto™ or Image Capture to transfer photos.
- Photos are stored in a DCIM folder (digital camera images) on your iPod. You can also transfer images to your computer by opening this folder and dragging them to the desktop. iPod must be enabled for use as a hard disk. For more information about using an iPhoto or Image Capture, see the instructions that came with the application.

NOTE: Disconnect the Media Reader when not in use to preserve battery life. Belkin recommends use of high-quality alkaline batteries in the Media Reader. Battery life depends greatly on the type of media being used and the type of battery being used; however, a single set of high-quality alkaline batteries should allow transfer of 24 or more typical 128MB CompactFlash cards (3GB or more of data).

Illuminated LED Reference

Solid Green – Power/Full Battery


Solid Amber – Low Battery

Flash – Media transfer to and from the Media Reader

NOTE: You can still transfer data until the battery dies. We strongly suggest verifying on the iPod user interface that all files were transferred if performed during low-battery status. If the transfer did not go through, insert new batteries and redo the entire transfer again.

Compatibility Chart – Types of Media

Supports CompactFlash® (Type 1 and 2)
SmartMedia™
Secure Digital (SD)
Memory Stick®
MultiMediaCard (MMC)



Graphic image indicates label/graphic side of media card faces up

.

FCC Statement

DECLARATION OF CONFORMITY WITH FCC RULES FOR ELECTROMAGNETIC COMPATIBILITY

We, Belkin Corporation, of 501 West Walnut Street, Compton, CA 90220, declare under our sole responsibility that the product:

F8E461

to which this declaration relates:

Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE Declaration of Conformity

We, Belkin Corporation, declare under our sole responsibility that the product F8E461, to which this declaration relates, is in conformity with Emissions Standard EN55022 and with Immunity Standard EN55024, LVP EN61000-3-2, and EN61000-3-3.

ICES

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme á la norme NMB-003 du Canada.

N10117